

Invited presentation at Sydney & J.L. Huffines Institute of
Sports Medicine and Human Performance,
Texas A&M University, February 10th, 2023



Monitoring Human Health and Performance using Body-worn Motion Sensors*

Kyoung Jae Kim, PhD, HHPC, KBR, Houston, TX

Jeffrey Somers, NASA Johnson Space Center, Houston, TX

*This work was funded by NASA Exploration Capabilities.



Presenter

KJ Kim, PhD

Human Performance Data Engineer
H-3PO Lab | HHPC | KBR

BACKGROUND

- Joined the Human Physiology, Performance, Protection & Operations (H-3PO) Laboratory in 2019.
- Perform research and provide operational expertise in several technical areas:
 - Exercise Physiology & Countermeasures (EPC)
 - Space Suits & Exploration Operations (SSEO)
 - Applied Injury Biomechanics (AIB)
- The biggest challenge in my career has been transitioning from a 'Signal Processing Engineer' to a 'Rehabilitation Engineer' to a 'Human Performance Engineer.'
- Publications of 24 refereed journal articles, 40 conference proceedings & abstracts, 15 registered patents (USA, Europe, Japan, and South Korea).
- **KBR's Tech Fellow** in Human Health & Performance – Signal Processing
- **NASA JSC Director's Innovation Award** for the development of multiple innovation processes that increase efficiency and improve accuracy in analyzing biomechanics and physiological data.

EDUCATION & TRAINING

- BS/MS/PhD: Electrical Engineering, Hanyang University, South Korea
- Postdoctoral at the University of Miami Physical Therapy

FUN FACT

- I love chicken wings, but those always make my stomach uncomfortable.




NBL testing




Egress testing

- What is an inertial measurement unit (IMU)?
- Why do we need to monitor human motion via IMUs?
- Applications for the astronaut population.





■ *Inertial Measurement Unit (IMU)*

- A wearable motion sensor measures multi-axis
 - accelerations (accelerometer),
 - angular rates (gyroscope), and
 - direction of magnetic north (magnetometer).
- Wireless, body-worn, small, portable, and not constrained by time and place.
- Weaknesses:
 - Displacement error due to integration
 - Magnetic field distortion



APDM



XSENS

Frequent assessments

Objective evaluation

Continuous monitoring

Increased sensitivity

Daily activity measures

Reduced cost burden
(No gait lab needed)



Addressing the pressing issues that affect human health and performance while incorporating new technology

A Big Change in the Spacesuit

- NASA's spacesuits are making a big change.



Lunar geology during Apollo 15 EVA
(Photo credit: NASA)



Mark III spacesuit during ARGOS testing



Next-generation spacesuit for the Artemis mission
(Image credit: NASA)

Walking will be one of the common exploration tasks on the Moon during the Artemis program.



Why is Gait Analysis Important?

- To help NASA scientists and engineers evaluate gait dynamics and performance in unsuited and suited conditions.
- To demonstrate unique characteristics and limitations of EVA training facilities.

[Unsuited] Lower-limb kinematics during walking



[Suited]



The strategies to adapt to walking environments affect gait dynamics and the related metabolic cost.


Planetary analog test site (rock yard) at NASA JSC




[Complex terrain]

- Locomotion on the moon could be challenged by terrain conditions. How much energy is consumed to adapt to Lunar terrain?


Metabolic rate



Upper body sway



Foot movement trajectory



Gait regularity: 91%

Gait regularity: 48%

NEEMO (NASA Extreme Environment Mission Operations)


■ Aim

- To investigate changes in sensorimotor performance due to exposure to the extreme mission environment.



■ Method

- Instrumented crewmembers using body-worn IMUs
- Measured performance of tandem gait (dynamic balance)

Tandem Walk



Tracking COM during walking



Kim, et al. (2018) Exposure to an extreme environment comes at a sensorimotor cost. *Nature - npj Microgravity*.

Automated Activity & Posture Classification


Next Generation Exploration Spacesuit




**Applied to the ARTEMIS Test Series at NBL*




Various activities and postures during ARGOS testing



IMU + Machine Learning





% (cumulative time) of Activity and Posture




*Total duration: 38m 9s

** We are currently characterizing activities and postures to have quantitative data for work-domain and engineering evaluation of the next generation spacesuits.*

- IMU location on the upper body




- Movement trajectory from **inside** and **outside** IMUs during walking




- Findings & lesson learned
 - The trunk IMU measured the upper body sway during walking, a butterfly-like pattern.
 - The inside upper body drives the outside suit.


- IMU location on the lower limbs



- Knee angular velocity calculated from thigh/shank IMUs



- Gait pattern from **inside** and **outside** IMUs



- Findings & lesson learned

- Two IMUs on the thigh and shank enabled to monitor knee joint angular velocity.
- The inside upper body drives the outside suit.
- The IMU system is the one and only device to perform inside-outside motion analysis.